

**BLOCK**

# High-Speed Identification of Trace Chemicals on Conveyor-Driven Parcels

Derek Wood, Alyssa Montalbano, Leyun Zhu,  
Wynn Bowers, Dimitry Maltsev, and Anish Goyal


**2023 SPIE Defense + Commercial Sensing**

2 May 2023

\*This work was supported under the U.S. Department of Homeland Security, Countering Weapons of Mass Destruction Office, competitively awarded contract 70RWMD20C0000006. This support does not constitute an express or implied endorsement on the part of the Government. The Government is authorized to reproduce and distribute reprints for Governmental purposes notwithstanding any copyright annotation thereon.

# Laser-Based, Long-Wave Infrared (LWIR) Hyperspectral Imaging (HSI)

- Powerful method for detecting, identifying, and mapping trace chemicals on surfaces
  - Most chemicals have strong and unique absorption spectra in the LWIR
  - High sensitivity & specificity, eye-safe
- Measure the spectral reflectance from a surface using an EC-QCL + Camera




See: Goyal, et al., SPIE Optical Engineering, Special Issue on Active Spectroscopy (2020)

- Most of the core technology is common for all variants
  - lasers, electronics, software, algorithms
- Camera is most important differentiator (performance vs cost)


**High-Performance**  
(MCT Camera)

**Low-Cost**  
(Microbolometer Camera)


Long-Range Standoff




Parcels on  
Conveyor Belt



Vehicle Checkpoint



First Responders /  
Site Assessment



- Prototype Trace Chemical Detector (TCD) was developed under the IARPA SILMARILS program
- MCT camera operated in windowed mode for high speed
  - 6,400 fps with window of 32 x 128 pixel
  - Imaged area of 13 x 52 mm
- Motorized camera lens with fast focus of < 100 ms
- Laser source combines the light from 3 EC-QCLs


<b>Camera type</b>	Liquid-nitrogen cooled MCT
<b>Camera frame rate</b>	1,600 fps (128 x 128 pixels) 6,400 fps (32 x 128 pixels)
<b>Standoff distance</b>	1.5 – 2.5 m, motorized
<b>Spatial resolution @ 2 m</b>	0.4 mm / pixel
<b>Wavelength range</b>	7.3 – 11.2 $\mu\text{m}$
<b>Laser power</b>	~25 mW average power

### SILMARILS Prototype Trace Chemical Detector



- Automatically measures, detects, and reports contamination on parcels moving at speeds up to 400 ft/min (2 m/s)
- A light curtain measures the height, length, and speed of parcels
  - From thin envelopes to parcels as tall as 1 meter
- Acquisition
  - Automatically starts and ends acquisition based on measured length and speed
  - Camera focus based on package height
  - Laser centered on camera FOV based on height


## Photograph of Testing Setup



## Principle of Data Acquisition

- Continuously measure a stationary 13mm (0.5") circular spot while the parcel is conveyed
  - Wavelength is tuned from 7.3 – 11.2  $\mu\text{m}$
  - Full sweep in less time than move one beam size
  - Hypercube stripe across top surface of entire parcel
- Result is a 32 x N pixel hypercube
  - Typical 40cm box  $\rightarrow$  N = 1000 pixels
  - Demonstrated acquisition up to 400 ft/min
- Most of the data was measured at 50 ft/min

Speed		Spectral Channels	Spectral Resolution	
m/s	[ft/min]		[ $\mu\text{m}$ ]	[ $\text{cm}^{-1}$ ]
0	0	306	0.01	1.3
0.4	80	161	0.02	2.7
0.8	160	91	0.04	4.9
2	400	48	0.08	9.2



## Pentaerythritol on Cardboard Box


- Contamination in 2 locations
  - Heavy fingerprint
  - Light smear
- Moving at 50 ft/min
- Scanned area of 1.3 x 66 cm
  - 32 x 1650 pixels

Box on Conveyor




Contrast-Enhanced Image of Box

Upper Scan →  
 Light smear →  
 Heavy Fingerprint →  
 Lower Scan →




Hyperspectral Images (not to scale / avg over wavelengths)



Contamination

Upper Scan




Contamination

"Fragile" Sticker

Lower Scan

- Compare the reflectance in the various regions
- Subtract substrate reflectance from that in the heavily contaminated region
  - Reasonably good correspondence with reflectance from bulk powder
- Pentaerythritol is readily identified


## Reflectance Spectra



Substrate  
subtraction




## Reflectance minus Clean Substrate






- Clear signature observed even for a light smear
- After substrate subtraction, chemical signature is clearly observed
  - Correlates with absorbance (imaginary index) of pentaerythritol
  - Signature as expected for a thin film on a dielectric substrate

### Reflectance Spectra




Substrate subtraction  
➔


### Reflectance minus Clean Substrate




- An extensive testing campaign was performed to determine the LODs
  - Multiple types of packaging surfaces, contaminants, and deposition methods
  - LODs depend on all of these factors
  - Shape of the spectra depends on deposition method
- In general, trace contamination was detected at concentrations of  $\sim 100 \mu\text{g}/\text{cm}^2$ 
  - Able to measure as low as  $10 \mu\text{g}/\text{cm}^2$  for specific contaminant/substrate combinations
  - Example of  $30 \mu\text{g}/\text{cm}^2$  solvent deposition on FedEx Mailer; intermediate signature






Substrate subtraction



- Developed automated segmentation algorithm
  - Distinguish and identify many common parcel materials
  - Extract “clean” local substrate reflectance to optimally subtract background spectrum
- The segmentation algorithm is robust for this parcel screening application
- Detection algorithm applied to each segment



- System has a simple user interface
- Operation of system is continuous and fully automatic
  - Arm system
  - Acquire measurement
  - Automatically process data
  - Display detection results
  - Save data
- Good results on actual parcels with complex surfaces
  - Stickers, labels, tape, etc.



- Successfully demonstrated the detection of trace chemicals on parcels while moving on a conveyor belt
- System can accommodate speeds up to 400 ft/minute (2 m/s)
- Detect contaminants on a wide variety of parcel surfaces
- Typical LODs of  $\sim 100 \mu\text{g}/\text{cm}^2$ , reaching as low as  $10 \mu\text{g}/\text{cm}^2$  depending on surface and contaminant chemistry
- Automated interface provides continuous monitoring of conveyed goods

*Acknowledgements: We thank DHS for their support of this project.*